





416 UPPER CONVERSION KIT FOR WA M4 SERIES PARTS LIST



(0909A-M4) BOLT CARRIER



(0909A-A9) EJECTION PORTCOVER




(0909A-B14) COVER SPRING




(0909A-A10) COVER HINGE PIN



(0909A-A10B) COVER HINGE PIN SNAP RING



(0909A-M1) UPPER RECEIVER



(0909A-A20) PLUNGER ASSEMBLY




(0909A-A21) FORWARD ASSIST PAWL



(0909A-B3) (Ø12.4×45) FORWARD ASSIST SPRING



(0909A-B4) (Ø3×9) PAWL SPRING



(0909A-M5) CHARGING HANDLE



(0909A-B18) (Ø2.5×16.5) FORWARD ASSIST RETAINER



(0909A-B19) (Ø2×9) PAWL SPRING PIN




(0909A-A19) CHARGING HANDLE LATCH



(0909A-B17) (Ø1.5×7) CHARGING HANDLE PIN



(0909A-B5) (Ø3.8×17) CHARGING HANDLE SPRING



(0909A-C1) GAS BLOK



(0909A-B20) M4*6



(0909A-A3)



(0909A-A7)



(0909A-A8)



(0909A-A5)




(0909A-A6)


PISTON ROD SET




(0909A-A4) GAS PISTON



(0909A-A1) OUTER BARREL



(0909A-A2) BARREL NUT



(0909A-M3) FRONT RAIL



(0909A-A22)




(0909A-A23)



(0909A-B26)
(Ø2.5×6)
PIN×4




(0909A-B23)
(Ø0.8×4)



(0909A-M2) LOWER RECEIVER



(0909A-A24)



(0909A-A13)
PIVOT PIN



(0909A-A14)
TAKEDOWN PIN



(0909A-A15)
TAKEDOWN
PIN & PIVOT
PIN DETENT×2



(0909A-B9)
(Ø2.3×25)
TAKEDOWN
PIN & PIVOT
PIN SPRING×2




(0909A-A27)
BUFFER RETAINER



(0909A-B10)
(Ø3×24)



(0909A-B1)
(Ø3.8×23)
BUFFER
RETAINER SPRING



(0909A-C2)
MAGAZINE
CATCH



(0909A-B8)
(Ø7 × 24.5)
MAGAZINE
CATCH SPRING



(0909A-A12)
MAGAZINE
CATCH BUTTON




(1006A)
SAFETY
SELECTOR



(0909A-A16)
SELECTOR DETENT



(0909A-B2-A)
(Ø3.8×14)
SELECTOR SPRING



(0909A-B21)
(Ø2.9×33)
SELECTOR
SPRING